

Table Of Contents

Introduction	1-1		
An Important Message To You From Zero	1-1		
Introduction	1-1		
Index	1-1		
Useful Information For Safe Riding	1-2		
Plug in Your Z-Force Power Pack™	1-2		
Owner Information	1-3		
Power Pack Serial Number	1-4		
Motor Serial Number	1-4		
Key Code Number	1-4		
Vehicle Identification Number (VIN)	1-4		
VIN Location	1-4		
VIN Break Down	1-5		
General Information	1-6		
Zero S Technical Specifications	1-6		
Zero DS Technical Specifications	1-7		
Vehicle Range	1-9		
Optimizing Your Range By Adapting Your Riding Style	1-9		
Public Charging Stations	1-10		
Emissions Information	1-10		
		Transporting	1-11
		Safety Information	2-1
		General Safety Precautions	2-1
		Important Operating Information	2-2
		Location Of Important Labels	2-3
		Throttle And Speed Control Label	2-4
		Performance Specifications/ Operation Guidelines	2-4
		Performance Envelope	2-4
		Z-Force Air Induction System	2-5
		Controls And Components	3-1
		Motorcycle Controls	3-1
		Left Side View	3-3
		Right Side View	3-5
		Instrument Panel	3-7
		Indicators	3-8
		Handlebar Controls	3-10

Starting And Operating	4-1
First Time Set-Up	4-1
Unpacking Your Zero Motorcycle	4-2
General Operation	4-4
Pre-Ride Inspection	4-4
Key Switch/Fork Lock Positions	4-5
Main Service Power Cut-Off	4-6
Power Pack	4-7
Operating Your Motorcycle	4-16
Suspension Adjustment	4-17
Maintaining Your Motorcycle	5-1
Owner's Responsibilities	5-1
Bolt Torque Table	5-2
Power Pack	5-5
General Maintenance	5-6
Motor	5-6
Brakes	5-6
Suspension	5-8
Wheels And Tires	5-8
Tire Inflation	5-9
Drive Belt	5-9
Drive Chain (optional)	5-13

Headlight Alignment	5-16
Headlight Bulb Replacement	5-17
Turn Signal Light Bulb Replacement	5-19
Brake/Tail Light Bulb Replacement	5-19
Running Light Bulb Replacement	5-20
Cleaning	5-21
Parking And Long Term Storage	5-22
Maintenance Schedule	5-23
Parts/Maintenance Items	5-26
Zero Motorcycle Accessories	5-26
Fuses	5-26
Troubleshooting	6-1
Power Pack And Charger	6-1
Understanding Beep Sequences	6-3
Safety Interlocks	6-6
Motor Temperature Indicator	6-8
General Troubleshooting	6-14

Warranty/Customer Assistance	7-1
Customer Assistance	7-1
Warranty Information	7-2
Zero Motorcycles Limited Warranties.....	7-3
Standard Warranty	7-3
Extended Warranty	7-4
Disclaimers Applicable to Standard	
Warranty and Extended Warranty	7-5
Proper Use	7-6
Purchaser's Responsibilities	7-6
Warranty Procedures	7-6
Transfer Of Ownership And Warranty	7-7

[illegible]

An Important Message To You From Zero

Congratulations and thank you for purchasing the 2011 Zero S/DS electric motorcycle; we welcome you to the community of Zero motorcycle riders. This manual is designed to provide you with a better understanding of the operation, inspection, and basic maintenance requirements of this motorcycle.

Zero continually seeks advancements in product design and quality. Therefore, this manual contains the most current product information available at the time of printing. Because of this, your motorcycle may differ from the information supplied in this owner's manual. No legal claims can be made on the basis of data in this manual. When it comes time to sell your Zero motorcycle, please remember to hand over this manual; it is, by law, an important part of the vehicle. If you have any questions concerning the operation or maintenance of your motorcycle, please contact Zero at support@zeromotorcycles.com.

Introduction

This manual covers the following motorcycles:

- S: Street
 - Integrated Z-Force Power Pack™ and Charger
 - Z-Force Air Induction System
 - Street Tires
 - Belt Drive
- DS: Dual Sport
 - Integrated Z-Force Power Pack™ and Charger
 - Z-Force Air Induction System
 - Dual Sport Tires
 - Belt Drive

Index

A good place to locate information about the motorcycle is in the index in the back of the manual. The terms “right” or “left” refer to the rider's right or left when sitting on the motorcycle.

Useful Information For Safe Riding

This manual contains the word CAUTION to tell about something that could hurt you or others. It also contains the word WARNING to tell about things that could damage your motorcycle.

CAUTION: Please read this manual carefully and completely before operating this motorcycle. Do not attempt to operate this motorcycle until you have attained adequate knowledge of its controls and operating features, and until you have been trained in safe and proper riding techniques. Regular inspections and proper maintenance, along with good riding skills, will help you to safely enjoy the capabilities and the reliability of this motorcycle. Disregarding the aforementioned, however, may render the warranty invalid.

Plug in Your Z-Force Power Pack™

WARNING: Proper care of the motorcycle's power pack is essential! When not in use, the power pack should be left on the charger even if fully charged. Failure to do so could damage the power pack and therefore void your power pack warranty. See page 4-7 for other important information about the power pack.

Owner Information

Record important information pertaining to your motorcycle here. When contacting your Certified Service Center (CSC), you may need to provide this information.

CSC Information	Motorcycle Information
Name _____	VIN _____
Address _____ _____ _____	Model _____
	Power Pack Serial Number _____ _____
Telephone No. _____	Motor Serial Number _____ _____
E-mail _____	
Date of Purchase _____	Key Code _____

Power Pack Serial Number

The Power Pack serial number is located on the upper right rear of the power pack.

Motor Serial Number


The motor serial number is stamped on the silver metal cooling band that wraps around the motor.

Key Code Number

The key code is a 5 digit number used to create duplicate keys. This number is located on a tag that accompanies the original keys.

Vehicle Identification Number (VIN)


VIN Location



See Location Of Important Labels on page 2-3.

VIN Break Down

The VIN is a 17-digit number stamped on the head tube of the frame. Do not alter or remove this number as it is the legal identifier for your motorcycle.



General Information

Zero S Technical Specifications

MOTOR	
Type	High Efficiency, Forced Air Cooled, DC, Axial Flux, Permanent Magnet
Estimated Top Speed	108 km/h (67 mph)
POWER SYSTEM	
Type	Z-Force™ Patented Li-Ion Intelligent Power Pack
Maximum Capacity	4.4 kWh
Nominal Capacity	3.9 kWh
Maximum Range	Up to 93 km (58 miles)
EPA UDDS* Range	70 km (43 miles)
Recharge Time (standard)	4 hours
Quick Recharge Time (optional)	2.3 hours (100% charged) 2 hours (90+% charged)

*Environmental Protection Agency (EPA) Urban Dynamometer Driving Schedule (UDDS)

POWER SYSTEM	
Input**	Standard 120 V AC or 240 V AC
Charger Type	Integrated
Estimated Power Pack Life (to 80%)	112,000 km (70,000 miles)
DRIVETRAIN	
Transmission	Clutchless one speed
Drive System	28T/98T Sprockets, 8 mm pitch, 200 tooth, 14 mm width, Poly Chain® (belt)
CHASSIS/SUSPENSION/BRAKES	
Front Suspension Travel	140 mm (5.5 in)
Rear Suspension Travel	151 mm (5.9 in)
Front Brakes	2 Piston Hydraulic, Stainless Rotor, Hand Actuated
Rear Brakes	1 Piston Hydraulic, Stainless Rotor, Foot Actuated
Brake Rotor Minimum Thickness	3.85 mm (0.15 in)
Front Tire	110/70-17 in
Rear Tire	130/70-17 in

**Zero chargers typically draw as much as 10 amps.

CHASSIS/SUSPENSION/BRAKES	
Front Wheel	17 x 3.0 in
Rear Wheel	17 x 3.5 in
DIMENSIONS	
Wheel Base	141 cm (55.5 in)
Seat Height (standard)	83.2 cm (32.8 in)
Low Seat Height (option)	78.1 cm (30.8 in)
Rake	22.7 degrees
Trail	71 mm (2.8 in)
WEIGHT	
Frame	8.8 kg (19.3 pounds)
Curb Weight	135 kg (297 pounds)
GVWR	271 kg (597 pounds)
Carrying Capacity	136 kg (300 pounds)
ECONOMY	
Typical Cost to Recharge	\$0.48

Zero DS Technical Specifications

MOTOR	
Type	High Efficiency, Forced Air Cooled, DC, Axial Flux, Permanent Magnet
Estimated Top Speed	108 km/h (67 mph)
POWER SYSTEM	
Type	Z-Force™ Patented Li-Ion Intelligent Power Pack
Maximum Capacity	4.4 kWh
Nominal Capacity	3.9 kWh
Maximum Range	Up to 93 km (58 miles)
EPA UDDS* Range	70 km (43 miles)
Recharge Time (standard)	4 hours
Quick Recharge Time (optional)	2.3 hours (100% charged) 2 hours (90+% charged)

*Environmental Protection Agency (EPA) Urban Dynamometer Driving Schedule (UDDS)

POWER SYSTEM	
Input**	Standard 120 V AC or 240 V AC
Charger Type	Integrated
Estimated Power Pack Life (to 80%)	112,000 km (70,000 miles)
DRIVETRAIN	
Transmission	Clutchless One Speed
Drive System (standard)	28T/98T Sprockets, 8 mm pitch, 200 tooth, 14 mm width, Poly Chain® (belt)
Drive System (optional)	13T/51T Sprockets, 420 Chain
CHASSIS/SUSPENSION/BRAKES	
Front Suspension Travel	240 mm (9.4 in)
Rear Suspension Travel	196 mm (7.7 in)
Front Brakes	2 Piston Hydraulic, Stainless Rotor, Hand Actuated
Rear Brakes	1 Piston Hydraulic, Stainless Rotor, Foot Actuated
Front Tire	100/80-17 in
Rear Tire	110/90-16 in

**Zero chargers typically draw as much as 10 amps.

CHASSIS/SUSPENSION/BRAKES	
Front Wheel	17 x 2.15 in
Rear Wheel	16 x 3.0 in
DIMENSIONS	
Wheel Base	143 cm (56.3 in)
Seat Height (standard)	90.8 cm (35.8 in)
Low Seat Height (optional)	85.7 cm (33.8 in)
Rake	24.9 degrees
Trail	71 mm (2.8 in)
WEIGHT	
Frame	8.8 kg (19.3 pounds)
Curb Weight	135 kg (297 pounds)
GVWR	271 kg (597 pounds)
Carrying Capacity	136 kg (300 pounds)
ECONOMY	
Typical Cost to Recharge	\$0.48

Vehicle Range

The range of an electric vehicle is defined as the distance the vehicle will travel on a single full charge of the power pack. Just like EPA mileage estimates on an automobile, “your mileage may vary.” Your range results are a direct reflection of your riding habits. The more conservative you ride the better range you can expect from your Zero S/DS motorcycle.

Some of the factors which affect range include speed, acceleration, number of starts and stops, as well as changes in elevation. The combination of these factors, as you travel from one point to another, defines your trip profile. In addition, tire pressure and payload are important considerations.

We suggest that you ride conservatively when you first get your Zero S/DS motorcycle, and get to know your motorcycle and your commute. Once you become familiar with the range versus performance of your motorcycle, then you can adjust your riding characteristics if you so desire. This applies mainly to riders with trip profiles which are at the edge of the performance envelope. Those individuals with relatively short commutes can expect to ride quite aggressively and reach their destination with energy to spare.

An average rider can expect to achieve 64 km (40 miles) of average range under normal use (stop and go traffic), with a maximum range of 93 km (58 miles) of steady riding at 40 km/h (25 mph). You can expect to achieve 48 km (30 miles) of range on the freeway of steady riding at 89 km/h (55 mph).

Optimizing Your Range By Adapting Your Riding Style

- Apply the throttle slowly and try to match the motorcycle's acceleration with your throttle position.
- Hard acceleration will decrease your range.
- If 108 km/h (67 mph) can be reached at 100% throttle, 75% throttle will give you about 89-95 km/h (55-59 mph) (a 25% energy savings for an approximate 12% speed loss).
- Coasting whenever possible makes a significant difference; the motorcycle will coast for a long distance (take advantage of this).

Public Charging Stations

There are more public charging stations coming on-line every day and there may be some in your area. You can charge from a public charging station with the optional J1772 S/DS Zero motorcycle accessory. These stations are often available at a variety of locations including shopping centers, city parking lots, airports, hotels, government offices, and other businesses. We recommend that you search the internet for locations in your area. For example, search for “charging stations.”

Emissions Information

The Zero S/DS electric motorcycle is a true freeway capable zero emissions vehicle under California (CARB), U.S. Federal (EPA), and European Union standards. It uses no gasoline or other liquid fuel. It has no tailpipe and therefore no tailpipe emissions. It also has no exhaust or evaporative emissions. Because the Zero S/DS runs solely on electricity, it is the only kind of vehicle which actually gets cleaner in terms of air pollution each year, as the electricity grid gets cleaner and more renewable. Zero Emissions Vehicles (ZEV's) offer greater efficiency, and can help solve the serious air pollution, global warming, and energy security problems facing the country and the world.

Emissions

The Zero S/DS doesn't require any gasoline and, as a result, does not get 'miles per gallon.' For the sake of emissions comparisons, the EPA estimates there to be about 33.705 kilowatt hours in one gallon of gasoline (33.705 kWh/gal). When operating a Zero S/DS we estimate that you will use 3.7 kWh before recharging. Based on the EPA estimate, 3.7 kWh is equivalent to .10978 gallons. With that .10978 gallons a rider can travel up to 93 kilometers (58 miles). This means that the Zero S/DS achieves incredible efficiency of 528.35 MPG.

Calculation


EPA Electric vs. Gas Equivalent: 33.705 kWh/gal
Energy used riding the Zero S/DS: 3.7 kWh
Range of the Zero S/DS: 58 miles
MPG= 58 miles/[3.7 kWh/33.705 kWh]
MPG= 528.35 miles

WARNING: Please use only Zero approved parts and accessories for your Zero motorcycle. Parts and products for your Zero motorcycle have been checked and tested for safety and suitability. Zero is unable to accept any liability whatsoever for parts and accessories which have not been approved.

Transporting


When the front fork is compressed, the built up pressure must be released to help prevent fork seal leaks. There is a 3 mm Allen “bleed” screw located just in front of the rebound adjuster on each fork leg. This “bleed” screw (A) is used to release the built up pressure. Loosen the screw slowly, but do not remove. Once all the air is out, tighten the bleed screw.

When the fork is released, with no weight on the front tire, the screw must be opened again to allow for stabilization. Ensure that the screw is tightened before riding.




It is recommended that the motorcycle be tied-down using ratchet straps. Place the ratchet straps around a frame contact point. Soft straps must be used to prevent scratches or other damage.

Use two ratchet straps in the front and two in the rear. The tie down straps should be at a 45° angle from the motorcycle. Follow the manufacturer's instructions for the ratchet straps you are using.



The electrical system must be disconnected when transporting or shipping.

Disconnect the main service power cut-off. See Main Service Power Cut-Off on page 4-6.
Remove the 58 volt fuses (A) from the fuse center.



The 58 volt fuse center is located on the back upper left corner of the power pack. See page 5-28 for further information.

General Safety Precautions

1. This is a performance motorcycle and should be treated with extreme caution.
2. Proper safety gear, including a regionally approved helmet, riding boots, gloves, and protective clothing should be worn while riding to reduce the risk of potential injury. We highly recommend the use of full height riding boots since the vast majority of motorcycle injuries are leg and foot injuries. It is not recommended to ride without protective clothing; this applies to even short journeys, and to every season of the year.
3. Read all additional warnings and product instructions in this owner's manual, and safety labels, before operating the electric motorcycle.
4. Never carry a passenger. This motorcycle is designed for a SINGLE RIDER ONLY.
5. Never permit a guest to ride your electric motorcycle without proper instruction. These are performance motorcycles and should be treated with extreme caution.
6. Do not ride on wet, frozen, oily or pitted surfaces. Avoid potholes, surface cracks, and other obstacles.
7. Never use alcohol or mind-altering drugs before operating an electric motorcycle.
8. Persons unwilling or unable to take responsibility for their actions should not use this motorcycle. You assume all responsibility while operating your motorcycle. The seller will assume no liability for misuse or operator negligence.
9. Prior to each use the rider must check everything in the "every ride" column of the maintenance schedules on pages 5-23 through 5-25, and the power pack function level as indicated on the instrument panel charge indicator.
10. Your safety depends in part on the good mechanical condition of the motorcycle. Be sure to follow the maintenance schedule and adjustment requirements contained in this manual. Be sure you understand the importance of checking all items thoroughly before riding.

11. Modifications of the motorcycle may render the vehicle unsafe and may cause severe personal injury. Zero Motorcycles cannot be held liable for non-approved modifications.
 12. Be very careful when loading or adding accessories to your motorcycle. Large, bulky, or heavy items may adversely affect the handling and performance of your motorcycle.
 13. Failure to follow power pack storage and charging instructions, as described in this Zero Motorcycles Owner's Manual, may void the warranty of your Zero motorcycle. These guidelines have been rigorously tested to ensure maximum power pack efficiency and service.
2. Switch the power OFF when backing up or pushing the motorcycle while dismounted. It is possible to unintentionally twist the throttle, resulting in unexpected acceleration.
 3. Use the rear brake when you are stopped on an incline. **Do not hold the motorcycle using partial throttle or damage to the motor may occur.**
 4. The Zero S/DS power pack should be plugged in when storing the motorcycle for extended periods of time.
 5. Keep your Zero S/DS connected to the charger when your motorcycle is sitting in storage or if it will be sitting unused for more than 7 days.

WARNING: Charge the Zero power pack with the Zero charger.

The power pack must be charged within 24 hours if fully discharged, and charged within 60 days if stored fully charged. Zero recommends that you plug in your Zero motorcycle after 7 days even if charged. Please leave your Zero motorcycle plugged in whenever possible.

Important Operating Information


1. Always turn the key switch and the motor stop switch to the OFF position when not actively riding. It is very easy to forget that the motorcycle is powered up because it is silent. An accident can occur if the motorcycle is left powered up while getting on or off the motorcycle.
6. Always firmly apply the rear brake while turning the key switch ON or OFF.

7. The power pack does not require or tolerate deep discharging. To get the most power pack life, recharge each power pack immediately after each ride. Leaving a power pack in a discharged state will cause damage. See Charging The Power Pack on page 4-12.

Location Of Important Labels


The vehicle could contain the following information:

- Gross Vehicle Weight Rating (GVWR)
- Gross Axle Weight Rating (GAWR) Front and Rear
- Vehicle Identification Number (VIN)
- Rim Size
- Tire Pressure
- Date of Manufacture



- A. Throttle and Speed Control Label
B. Vehicle Identification Number (VIN) Label. See Vehicle Identification Number (VIN) on page 1-4
C. Vehicle Certification Label

Throttle And Speed Control Label

**IMPORTANT**

THROTTLE AND SPEED CONTROL

The fully electric drivetrain of this motorcycle is different than any gas counterpart:

- **There is no engine braking and no engine noise**
- When going into corners or coming to a stop you will be fully dependent on your brakes
- It is easy to find yourself speeding due to the absence of engine noise
- Passersby will not hear your approach - be extra cautious when making turns, entering intersections or when people are likely to cross your path

Be aware that your motorcycle is still ON during stops and while at an "idle". Accidentally twisting the throttle can cause serious harm.

Please read the user manual for more information prior to operating the motorcycle.

IMPORTANT

Performance Specifications/ Operation Guidelines

The Zero S/DS motorcycle is designed to provide many years of trouble free commuting and riding excellence. Please read the information below to get a sense for the motorcycle's performance abilities and limitations.


Performance Envelope

- An average rider can expect to achieve 70 km (43 miles) of average range under normal use (stop and go traffic), with a maximum range of 93 km (58 miles) of steady riding at 40 km/h (25 mph). You can expect to achieve 48 km (30 miles) of range on the freeway of steady riding at 89 km/h (55 mph).
- The Zero S/DS has the ability to start, from a standstill, up a steep 10% grade when fully loaded. It is not recommended that you stop on a grade of more than 10% with a fully loaded motorcycle.

Z-Force Air Induction System


The air induction system is a compact forced air delivery system. It consists of a powerful fan motor (A) located under the rear fender.

The fan is connected to the motor by means of a flexible duct. The system allows the motor to run cooler and increase power by efficiently moving air through the motor core. The fan will turn on briefly when the key switch is first turned on. The fan is automatically controlled by the motorcycle control unit and will turn on as the motor temperature increases. In the unlikely event that you exceed the motorcycle's performance capabilities, the motor temperature warning system will activate. See Motor Temperature Indicator on page 6-8.



[illegible]

Motorcycle Controls



- A. Mirrors
- B. Key Switch/Fork Lock
- C. Instrument Panel
- D. Front Brake Fluid Reservoir/Master Cylinder
- E. Front Brake Lever
- F. Throttle Control
- G. Motor Stop Switch
- H. Left Handlebar Control

A. Mirrors

This motorcycle is equipped with convex mirrors. A convex mirror has a curved surface. Convex mirrors offer a greater field of view than a similar flat mirror. However, the greater field of view makes objects seem further away than they really are. Care must be used when judging the distance of objects seen in these mirrors.

B. Key Switch/Fork Lock

For description and operation see page 4-5.

C. Instrument Panel

For description and operation see pages 3-7 through 3-9.

D. Front Brake Fluid Reservoir/Master Cylinder

For description and operation see Brakes on page 5-6.

E. Front Brake Lever

The front brake lever controls the front brake when the lever is squeezed. When braking, the throttle should be in the neutral/returned position. The brake light will illuminate when the brake lever is applied.

F. Throttle Control

For description and operation see pages 3-10 and 3-11.

G. Motor Stop Switch


For description and operation see pages 3-10 and 3-11.

H. Left Handlebar Control

For description and operation see pages 3-10 through 3-12.

Left Side View

- A. Headlight
- B. Main Service Power
Cut-Off
- C. Auxiliary Power Pack
Charging Connection
- D. Brake/Tail Light
- E. Rear Turn Signal
- F. Front Turn Signal
- G. AC Charger Power
Connection
- H. Integrated Power Pack
Charger
- I. Kickstand
- J. Kickstand Switch



A. Headlight

- For headlight operation, see Handlebar Controls on pages 3-10 and 3-11.
- For headlight bulb replacement, see Headlight Bulb Replacement on page 5-17.
- For headlight alignment, see Headlight Alignment on page 5-16.

B. Main Service Power Cut-Off

For description and operation, see page 4-6.

C. Auxiliary Power Pack Charging Connection

For description and operation, see Quick Charging on page 4-14.

D. Brake/Tail Light

For brake/tail light bulb replacement, see Brake/Tail Light Bulb Replacement on page 5-19.

E, F. Turn Signals

- For turn signal operation, see Handlebar Controls on pages 3-10 and 3-12.
- For turn signal light bulb replacement, see Turn Signal Light Bulb Replacement on page 5-19.

G. AC Charger Power Connection

For description and operation, see Charging The Power Pack on page 4-12.

H. Integrated Power Pack Charger

For description and operation, see Power Pack Charger on page 4-9.

I. Kickstand

The kickstand swings out from the side and supports the motorcycle when parked. The key switch should be in the OFF position when parked.


J. Kickstand Switch

This switch is a safety feature that prevents motor operation when the kickstand is down. If the kickstand were down when riding it could contact the ground causing you to lose control of the motorcycle and cause personal injury.

WARNING: Park only on a flat firm surface otherwise the motorcycle could fall over causing damage.


Right Side View

- A. Rear Brake Fluid Reservoir
- B. Drive Chain/Belt Adjuster
- C. Rear Brake Pedal
- D. Power Pack



- A. Rear Brake Fluid Reservoir
See Rear Brake on page 5-7.
- B. Drive Chain/Belt Adjuster
See Drive Chain Adjustment Procedure on page 5-15 or Drive Belt Adjustment Procedure on page 5-12.
- C. Rear Brake Pedal
The rear brake pedal controls the rear brake when the pedal is pressed. When braking, the throttle should be in the closed position. The brake light will illuminate when the rear brake pedal is applied.
- D. Power Pack
For description and operation see page 4-7.


Instrument Panel



- A. Left Turn Signal Indicator
- B. Motor Temperature Indicator
- C. High Beam Indicator
- D. Speedometer
- E. Main Power Indicator
- F. Charge Indicator


- G. Right Turn Signal Indicator
- H. Odometer
- I. Trip Odometer
- J. Adjust Button
- K. Select Button
- L. System Warning Indicator

Indicators



A and G. Turn Signals


An arrow on the instrument panel will flash green in the same direction as selected by the turn signal switch. This will remain on until the turn signal request has been canceled.



B. Motor Temperature Indicator

This indicator will blink in the unlikely event that you exceed the motorcycle's performance capabilities. The temperature warning indicator senses the temperature of the motor. See

Motor Temperature Indicator on page 6-8 for more information.



C. High Beam

When the headlight high beams are on, this indicator will illuminate blue and will remain on until the high beams are turned off.

D. Speedometer

The speedometer is an analog and digital display in either kilometers per hour (km/h) or miles per hour (mph).

E. Main Power Indicator

The main power indicator is ON any time the key is in the ON position. If the main power indicator is flashing, the system has detected a fault. For troubleshooting, see section 6.

F. Charge Indicator

This indicator displays the amount of energy remaining in the power pack, similar to the fuel gauge on a gasoline powered vehicle.

H. Odometer

The odometer displays the total distance the motorcycle has been ridden in kilometers or miles.

I. Trip Odometer

The trip odometer displays individual trip mileage, and is reset by pressing and holding the adjust button.

J. Adjust Button

By pressing the adjust button you can toggle between the trip odometer settings. Holding it down will clear the trip odometer resetting it back to zero.

K. Select Button



By pressing the select button you can change the display units that appear on the instrument panel between English or Metric.



L. System Warning Indicator

If a fault has been detected, count the number of times the red LED flashes. See the table on page 6-2.

Handlebar Controls




- A. High Beam Flash-to-Pass
- B. Headlight High/Low Beam Switch
- C. Front Brake Lever
- D. Throttle Control

- E. Motor Stop Switch
- F. Turn Signal Switch
- G. Horn Button

A. Flash-to-Pass

When the headlight is in the low beam position, push the flash-to-pass switch and the high beam will illuminate and will stay illuminated until the switch is released. When released, this switch will default back to the low beam position. The high beam indicator will also illuminate.



B. Headlight High/Low Beam Switch

When the switch is pushed, the headlight will change from low beam to high beam. It will stay in the selected position until it is switched back. When in high



beam position, the high beam indicator on the instrument panel will illuminate.

C. Front Brake Lever

The front brake lever controls the front brake when the lever is squeezed. When braking, the throttle should be in the closed position. The brake light will also illuminate.


D. Throttle Control

Twist the throttle in a counter-clockwise rotation (A) to energize the motor and start the motorcycle in a forward direction. Release the throttle and it will snap back to the closed position (B), de-energizing the motor.



E. Motor Stop Switch

When the switch (A) is pressed, it will stop power to the motor controller. The motor controller will remain in this state until the ON (B) button is pressed. The switch does not turn off all electrical circuits, just the operation of the motor.



F. Turn Signal Switch

When the turn signal switch is pushed in the left or right position, the corresponding front and rear turn signals will flash.

When the turn signal switch is ON, the corresponding turn

signal indicator on the instrument panel will illuminate.

Always signal your turns and other maneuvers as required by law. Unlike an automobile, the turn signals must always be cancelled manually on the motorcycle. Push in on the switch and it will return to the center, or, OFF position.

G. Horn Button

When the key is in the ON position, the horn will sound when the button is pressed. Electric vehicles run quietly; the horn can be used to warn pedestrians or other motorists of your presence.

First Time Set-Up

If your motorcycle was direct-shipped you will need to perform the following:

1. Remove the motorcycle from its shipping crate. See Unpacking Your Zero Motorcycle on page 4-2.
2. You must charge the power pack before riding the motorcycle. See Charging The Power Pack on page 4-12.
3. Identify and inspect wheels for spoke tension and/or damage.
4. Check the tire pressure and adjust to proper specifications. See Tire Inflation on page 5-9.
5. Inspect the hydraulic brake system. Follow the hydraulic line from the reservoirs to the calipers and verify that there are no leaks or damage to the brake lines. Verify that the brakes function properly.
6. Make sure the motorcycle key switch is OFF, then twist the throttle to make sure it's rotation is smooth, and it returns correctly.
7. Inspect bolts and make sure they are tight. See Bolt Torque Table on page 5-2. Double check the fork, wheel, and brake bolts.
8. Insert the key in the key switch, engage the rear brake, and turn the key to the ON position. The gauge will perform a self test sweep. The charge indicator should read fully charged.

Unpacking Your Zero Motorcycle

Although unpacking your Zero motorcycle can be done by a single person, it is recommended to have a second person to help lift and remove your motorcycle from the crate base.

Outer Box Cover

- Cut and remove the two plastic outer box retention straps.
- Unscrew stabilizer bar bolts, one on each side of outer box.
- Open box top and remove inner cardboard end reinforcement sleeves.
- Unscrew stabilizer bar from handlebar riser and remove.
- Unscrew lower crate cover retaining screws and washers.
- Lift or cut outer box away from motorcycle.

Inner Assembly

- Carefully remove plastic cover from motorcycle.
- Locate small parts box below motorcycle and put to the side. (This box contains important documentation, owner's manual, keys, handlebar clamps and hardware, etc.)
- Cut cable ties holding handlebar to motorcycle.
- Position and center handlebar in riser and mount using handlebar clamps and bolts located in the small parts box. Torque handlebar clamp bolts to 26 N•m (19 ft lb).
- Remove the retaining pin from the power pack rail.
- Remove power pack retaining frame rail.
- Remove power pack.
- Remove cam lock tie down straps and metal tie straps from crate base.

- Carefully lift rear portion of the motorcycle over the swingarm standoff and off crate base.
- Carefully lift front wheel out of crate base.
- Deploy kickstand, lean motorcycle and inspect in accordance with delivery inspection sheet.

Recycling

Your Zero Motorcycles shipping crate and packaging materials were designed to be completely recycled. Please cut down and recycle all cardboard, plastic, and metal materials in appropriate receptacles.

The tie down straps that accompanied your motorcycle can be reused as regular tie down straps for transporting your motorcycle.

General Operation

Pre-Ride Inspection

Before operating the Zero S/DS motorcycle, check the following to make sure the motorcycle is secure and intact:

- **Power Pack**

Make sure the instrument panel charge indicator is indicating a charged power pack. If the charge indicator reads below 6 bars (1/2), we suggest you recharge before use. Always keep the charger cord with the motorcycle.

- **Drive Belt**

Check the belt tension and condition. See Drive Belt on page 5-9.

- **Drive Chain (Optional)**

Check the chain tension and condition. Adjust and lubricate if necessary. The drive chain must be cleaned and lubricated at the intervals specified in the maintenance schedule; otherwise it will quickly wear out, especially when riding in dusty or wet areas. See Drive Chain on page 5-13.

- **Brakes**

Squeeze the brake lever and press the brake pedal individually while pushing the motorcycle to see if it rolls. You should be able to lock-up the wheels completely by applying the brakes.

- **Throttle**

With the key switch in the OFF position, apply the throttle and release to verify that the throttle is smooth and returns correctly.

- **Tires**


Check both tires for condition and tread depth. Check cold tire pressure frequently. Check for damage and alignment. Maintain correct tire pressure as specified on page 5-9. Replace the tires when the tread height is 2 mm (0.08 in) or less.

CAUTION: Under-inflation is the most common cause of tire failure and may result in severe tire cracking, tread separation, "blowout," or unexpected loss of motorcycle control causing personal injury and possible death. See Tire Inflation on page 5-9.

- **Electrical System**

Check for correct function of the headlight, turn signals, and the brake/tail lights.

Key Switch/Fork Lock Positions



This is a three-position switch that is located on the fork in front of the handlebar. The switch positions are as follows:

- A. Fork Lock
- B. OFF
- C. ON

The key should be removed from the motorcycle when parked to prevent theft. The key can be removed in either the OFF or fork lock position.

A. Fork Lock


Using the fork lock when parked will prevent unauthorized use and help prevent theft.

To Lock:

1. Turn the handlebar all the way to the left.
2. Push the key down from the OFF position and turn the key counter-clockwise while still pushing it in. See image on page 4-6.
3. Remove the key.

To Unlock:

1. Install the key and turn clockwise.
2. Remove the key.



B. OFF

This position is used to turn the motorcycle OFF.

C. ON

This position is used for operating the motorcycle. In this position the following will occur:


- Lights turn ON
- Cooling Fan turns ON briefly
- Instrument Panel display turns ON

Main Service Power Cut-Off

The main service power cut-off connection is located under the rear of the power pack. This connection is used to connect or disconnect the power pack from the motorcycle. When disconnected, all electricity to the motorcycle is turned off, this includes the charger. When charging or operating, the system must be connected. The system must be disconnected when transporting or shipping the motorcycle. See Transporting on page 1-11.


To Disconnect:

Pull the main service power cut-off connector loop (A).



To Connect:

Align the blue connectors (B) and push until fully connected.



Power Pack

The battery is located within the power pack and requires no special break in period. Under normal use and correct power pack maintenance, the power pack should maintain most of its capacity for approximately 5 years.

The charging time is the same if connected to 120 V AC or 240 V AC; this is an input to the charger. The charger output will be the same.

The normal recharging time of the power pack is usually less than 4 hours in ambient temperatures. Out of the normal temperature range charging and run-time times will vary. The power pack should not be used outside of the range of -7°C - 71°C (20°F - 160°F); the Battery Management System (BMS) will turn off the motor controller outside of this range.

It is required that you leave the motorcycle on the charger if you expect it to sit in storage or unused for over 7 days. The power pack must be charged within 24 hours if fully discharged, and charged within 60 days if stored fully charged. Zero recommends you plug in your Zero motorcycle after 7 days, even if fully charged. Please leave your Zero motorcycle plugged in whenever possible. The power pack should maintain up to 80% of its capacity, for approximately 112,654 kms (70,000 mi).

Add On Electrical Equipment

WARNING: Do not add anything electrical to your motorcycle unless approved by your CSC. Some electrical components can damage your motorcycle. Some add on electrical equipment can keep other components from working as they should or can dramatically reduce the range and/or life expectancy of the power pack.

Battery Management System (BMS)

Every power pack contains a Battery Management System (BMS) which monitors the condition of the cells, and optimizes the charging process to provide the highest-performance, longest-range, and longest-life for the power pack.

The BMS also monitors the power pack for a host of predefined conditions, and then takes actions according to these conditions. Some of these conditions are listed below. Also see, Understanding Beep Sequences on page 6-3.

- **Low Voltage**

Action: When a low voltage is detected, the beeper is sounded to alert the rider that he or she should stop riding the motorcycle. This beeper beeps approximately once every 10-12 seconds when the motorcycle is being ridden, and then once every minute when the motorcycle is inactive.

- **Dangerously Low Voltage**

Action: If the voltage drops to the point that may damage the battery cells, the battery sends a signal to disable the motor controller and the motorcycle will not run until the voltage returns to an acceptable level.

- **High or Low Temperature**

Action: If the BMS senses that the power pack is too hot, above 71°C (160°F), or too cold, below -7°C (20°F), it sends a signal to disable the motor controller and the motorcycle will not run until the temperature returns to an acceptable level. The charger will also be disabled in this condition.

- **High Voltage**

Action: If the BMS detects a voltage that is too high, it shuts down the charger to prevent over-charging.

The BMS is sealed inside the power pack. As a rider, you don't need to think much about the BMS - it just silently does its job as you charge, ride, and store your motorcycle. There are only two things you might need to know about your Z-Force BMS:

- **Beep-Signals**

The BMS will emit an "OK" beep-tone every time you turn-on your motorcycle. The BMS might also respond to other internal conditions and errors with different kinds of beeps. The following section explains the different beep-patterns and their meanings.

- **Safety Interlocks**

The BMS can disable the motorcycle's throttle control if the power pack is fully discharged, or in case of other errors. The BMS can also disable charging under certain circumstances. The information below explains the different conditions which can cause the BMS to disable the throttle control or the power pack charger.

Beeps

The BMS includes an electronic beeper, sealed inside the power pack. The beeper is located on the upper front left corner of the power pack.

The BMS will beep under only two circumstances:

- When the motorcycle is turned ON, the BMS will perform a self-test. It will always sound a beep-signal when the test finishes. The beep-pattern reports the self-test result.
- When the key switch is ON, and the power pack is nearly empty. The BMS will continuously sound a warning when the power pack is low. The warning will decrease in frequency and will still emit when the motorcycle is turned-off.

Power Pack Charger


Keep your power pack connected to the charger when your motorcycle is sitting in storage or if it will be sitting unused for more than 7 days. The power pack must be charged within 24 hours if fully discharged, and charged within 60 days if stored fully charged. Zero recommends you plug in your Zero motorcycle after 7 days, even if fully charged. Please leave your Zero motorcycle plugged in whenever possible.

Warning: Charge the Zero power pack with the Zero charger.


When charging the motorcycle's power pack, the charger (A) can be left ON, even after the power pack is fully charged (see image on page 4-10). There are two possible cases that can occur:

- When left on the charger the power pack will receive a full charge. Once fully charged, the charger will check the status of the power pack once every 72 hours to ensure that it maintains a full charge. When fully charged a green light will illuminate on the charger. Should the charger not read that the power pack is full, it will continue to attempt to fully charge the power pack. In this event the green light may not illuminate, however, the power pack may be fully charged. To ensure that the power pack is charged, check the charge indicator prior to riding.

- If the power pack terminates the charge before the charger reaches the state previously mentioned, then the charger will continue to cycle and will top off the power pack until the power pack is removed, or the charger reaches the complete state previously noted.



Charger LED Indicators



A. Ammeter

The Ammeter LED is an amber indicator that indicates that the current output is on, and should gradually ramp down from "|||||" to "I".

B. 80% Charge

The 80% Charge LED is an amber indicator. If it is on solid, the bulk charge phase is complete, 80% charged. Charger is now in absorption phase. If the indicator is flashing, there are two issues that can cause this to occur:

- The charger and BMS are balancing
- The BMS is cutting off the charge because one or more cells have reached maximum voltage.

C. 100% Charge

The 100% Charge LED is a green indicator. If it is on solid, the charging is complete and the charger will enter maintenance mode. If it is flashing, the absorption phase is complete and the charger is in finish phase.

D. AC ON

The AC ON LED is an amber indicator. If it is on solid, the AC power is good. If it is flashing, the AC voltage is low. Check for proper voltage, and if an extension cord is being used, verify that it is of the correct length. Maximum length is 7.6 m (25 ft.) 12-AWG.

E. Fault

The Fault LED is red indicator which indicates there is a charger error. If it is flashing, reset the charger and see section 6, Troubleshooting.

Charging The Power Pack

Your power pack is equipped with an “Emergency Energy Reserve Beep.” When your power pack makes an audible beep, it has only a few miles of range left. This beep tells you your power pack is dangerously low on energy and needs to be recharged immediately. Your power pack will continue to beep even when it’s charging until it has recovered its “Emergency Energy Reserve.”

WARNING: Charge the Zero power pack with the Zero charger.

It is possible for lithium ion cells to overheat and fail.

It is recommended to charge in a location that is away from combustible materials and in a well-ventilated area. If charging your Zero motorcycle outdoors, avoid charging in the rain.

The maximum power pack internal charging temperature is 52°C (125°F). If the power pack’s internal temperature is over 52°C (125°F), it will not accept a charge until it is moved to a cooler location. Also, if the power pack has just been run hard, it may internally be above 52°C (125°F) even if the ambient temperature is lower.


If you experience a power pack that will not take a charge, you should ensure the internal temperature is below 52°C (125°F). If the power pack was recently run and it will not take a charge, the power pack should cool and begin taking a charge in around 30 minutes or less.

The maximum charging temperature cutoff is a power pack longevity feature. Charging at higher temperatures can shorten the life of the power pack.

Note: Frequent top off charging is good for the power pack’s life span, so do not hesitate to charge frequently.

Standard Charging

1. Ensure that the key switch is in the OFF position.
2. Plug the supplied power cord (A) into the on-board charger connector (see image on page 4-13). Always keep the power cord with the motorcycle.




Note: AVOID connecting the Zero charger and another device to a single 120 V AC 15A/20A circuit, as it may become overloaded. Zero chargers draw as much as 10 amps from the 120 V AC circuit when charging.

3. Always connect the charger to a GROUNDED outlet. When using an extension cord, avoid excessive voltage drops by using a grounded, 3-wire, 12-AWG cord no longer than 7.6 m (25 ft). The charger can be used on 120 V AC or 240 V AC current. The voltage does not change the amount of time that the motorcycle takes to charge.


4. Charging a fully discharged power pack takes about 4 hours. When the power pack is fully charged, disconnect the power cord from the charger.

Quick Charging

The Quick Charge feature utilizes an auxiliary power pack connector (located at the rear of the power pack under a protective cover [A]) and external charger. This charger is used in addition to the integrated charger. Both chargers are used together to reduce overall charging time. Charging a fully discharged power pack takes between 2 to 2^{1/2} hours.



1. Ensure that the key switch is in the OFF position.
2. Locate the auxiliary charging connector and remove the protective cover. The connector is located at the rear of the power pack, next to the main service power cut-off.
3. Connect the power pack charger to the power pack connector (A).



4. Always connect the charger to a GROUNDED outlet. When using an extension cord, avoid excessive voltage drops by using a grounded, 3-wire, 12-AWG cord no longer than 7.6 m (25 ft). The charger can be used on 120 V AC or 240 V AC current. The voltage does not change the amount of time that the motorcycle takes to charge.
5. Connect the integrated charger. See Charging the Power Pack Single Charger (integrated) on page 4-12.
6. When the power pack is fully charged, disconnect the chargers and reinstall the protective cover.

Note: AVOID connecting the Zero charger and another device to a single 120 V AC 15A/20A circuit, as it may become overloaded. Zero chargers draw as much as 10 amps from the 120 V AC circuit when charging.

Operating Your Motorcycle

Starting

1. Turn the key switch to the ON position.
2. Verify that the charge indicator reads fully charged.
3. With the brake applied, press the motor stop switch to the ON position.
4. With the kickstand up, release the brake and twist the throttle toward you (counter-clockwise) to increase speed. When the throttle is twisted away from you (clockwise), the speed will decrease.

Braking

On the right handlebar is the hand operated brake lever. The brake lever controls the front brake when the lever is squeezed. On the right lower side, next to the foot peg, is the foot operated brake lever. This lever controls the rear brake. When braking, the throttle should be in the closed position.

CAUTION: If you apply the front or rear brake hard enough, it is possible to lock the wheels. This could cause you to lose control of the motorcycle. We suggest progressive use of the brakes to bring the Zero motorcycle to a complete stop without locking the wheels. Your Zero motorcycle is a light weight performance product and therefore practice is recommended to safely perfect emergency stops.

Stopping

1. With the throttle in the closed position and the brake applied, press the motor stop switch to the OFF position. This switch can also be used in an emergency to shut the motor off.
2. Turn the key switch to the OFF position and remove the key. To prevent theft, the key should be removed anytime the motorcycle is left unattended.
3. Be sure to charge the power pack after each ride. See Charging The Power Pack on page 4-12.


Suspension Adjustment

Front Fork Adjustment


A shock has two main actions: compression when the shock gets compressed, and rebound when the shock returns back to full length. Compression damping is the adjustment that determines how fast or slow the fork compresses. Rebound damping is the adjustment that determines how fast or slow the fork rebounds.

1. Bleed Screw - The 3 mm Allen M5 screw (A) at the top of the fork leg is the "bleed" screw. The bleed screw serves two purposes:
 - Transporting your motorcycle. See Transporting on page 1-11.
 - Bleeding the fork: Bleed the fork regularly, let any excess air out after each ride.

2. Rebound Damping - The rebound damping is adjusted by turning the slotted brass adjuster screw (B) on the top of both fork legs. Next to it will be the writing S-F, meaning Slow and Fast. The adjuster has 18 stages of adjustment. This determines how quickly the fork returns to its extended position after being compressed. Turning the rebound adjuster screw clockwise will slow the rebound speed down making it better for larger, rolling terrain or bumps. Turning the rebound adjuster screw counter-clockwise will increase the rebound speed making it better for smaller, rougher bumps. Adjust each fork leg evenly.



3. Compression Damping - The compression damping is adjusted by turning a screw on the bottom of each fork leg. There is a rubber dust cover protecting the jam nut (A) securing the screw (B). The adjuster has 12 stages of adjustment. Turn the adjuster clockwise for slower compression. To speed up compression, turn the adjuster counter-clockwise. Start with a middle setting and fine tune the compression from there. Proper compression will allow the tire to track the ground over consecutive bumps. Compression that is set too slow will pack-up (feel harsh over consecutive bumps) while compression that is set too fast will cause the fork to bottom out harshly. If the fork is bottoming out, turn the adjuster one click at a time until the bottom-out stops. Adjust each fork leg evenly. Replace the rubber dust cover after the adjustment.




Rear Shock Adjustment

Spring Adjustment:

Obtaining the correct rear spring rate is critical for proper handling. The spring rate must be set to match the weight of the rider. The spring is preloaded for an 82 kg (180 lb) rider. This puts the rear tire 1/3 of the way through its vertical travel. Heavier riders require stiffer spring rates. A good approximation of your rear spring requirements can be found by measuring the rear suspension's sag. This measurement will quickly determine if your rear spring is approximately correct for your weight. This adjustment is a recommended guideline; personal riding preference may vary from the specifications given.


- Checking Sag

1. Support your motorcycle on a stand with the rear wheel off the ground.
2. Measure vertically from the rear axle to the rear fender. Mark this spot as it will be used for other measurements.
3. Record this measurement, this will be measurement M1.



4. Remove the motorcycle from the stand.
5. Wearing your normal riding apparel, sit on the motorcycle.
6. Have an assistant hold the motorcycle up, your feet should be on both pegs.
7. Bounce the suspension a couple of times.

8. Have a second assistant take a measurement using the same locations as in step 2.
9. Record this measurement, this will be measurement M2.



10. Subtract the second measurement (M2) from the first measurement (M1).

Example:


M1		600 mm (23.6 in)
M2	-	500 mm (19.6 in)
Sag	=	100 mm (4 in)

The total sag is 100 mm (4.0 in). Refer to the chart below for the correct sag. If the sag is not correct, the spring pre-load should be adjusted. See Spring Pre-load Adjustment on page 4-21.


MODEL	SAG
S	45 mm (1.77 in)
D/S	65 mm (2.56 in)

- Spring Pre-load Adjustment
 1. Clean any dirt or debris from the threads of the shock near the lock ring (A).
 2. Using a lock ring wrench loosen the lock nut (A).
 3. For measurements less than the specified value, decrease the pre-load on the spring by turning the spring nut (B) counter-clockwise on the shock. If more than the specified value, increase the pre-load on the spring by turning the spring nut (B) clockwise on the shock.
 4. Recheck the sag. If the sag is correct, tighten the lock nut (A).
- Rebound Adjustment - The rebound adjuster knob (C) is at the bottom of the shock. It has 8 stages of adjustment. Printed on the knob is S-F, meaning Slow and Fast. The rebound adjuster knob controls how slow or fast the shock returns to its extended position after being compressed. Turning the knob clockwise, or S direction, is good for big impacts.

Turning the knob counter-clockwise, or F direction, is good for smaller and more frequent impacts.



- **Compression Adjustment** - The compression adjustment knob (D) is at the top of the shock. It has 18 stages of adjustment. The knob has + (slower compression) and - (faster compression). Turn the adjuster clockwise for slower compression. To speed up compression, turn the adjuster counter-clockwise. Start with a middle setting and fine tune the compression from there. Proper compression will allow the tire to track the ground over consecutive bumps. Compression that is set too slow will pack-up (feel harsh over consecutive bumps) while compression that is set too fast will cause the shock to bottom out harshly. If the shock is bottoming out, turn the adjuster one click at a time until the bottom out stops.



Owner's Responsibilities


1. This owner's manual should be considered a permanent part of this motorcycle and should remain with it even if the motorcycle is subsequently sold.
2. Perform routine care and maintenance of your electric motorcycle as detailed in this owner's manual.
3. Use only Zero approved parts and Zero Motorcycle Accessories.
4. The operator is responsible for learning and obeying all country, federal, state, and local laws governing the operations of an electric motorcycle.
5. Always wear a regionally approved helmet, goggles, appropriate boots, and all other appropriate safety equipment when operating an electric motorcycle.

Bolt Torque Table


LOCATION	ITEM	TORQUE	NOTES
A	Handlebar clamp mount bolts	26 N·m (19 lb ft)	-
B	Shock mount bolts	52 N·m (38 lb ft)	-
C	Rear caliper mount bolts	20 N·m (15 lb ft)	Use LOCTITE® 242®*
D	Front axle pinch bolts	18 N·m (13 lb ft)	Use LOCTITE® 244®*
	Front axle end bolts	26 N·m (19 lb ft)	Use LOCTITE® 242®*
E	Front caliper mount bolts	20 N·m (15 lb ft)	Use LOCTITE® 242®*
F	Main pivot bolt/nut (swingarm)	102 N·m (75 lb ft)	-
G	Rear axle pinch bolts	26 N·m (19 lb ft)	Use LOCTITE® 242®*
H	Rear axle end bolts	26 N·m (19 lb ft)	Use LOCTITE® 242®*
I	Triple tree pinch bolts	16 N·m (12 lb ft)	Use LOCTITE® 242®*
J	Headlight bolts	22 N·m (16 lb ft)	Use LOCTITE® 242®*
K	Motor mount bolts (front)	35 N·m (26 lb ft)	Use LOCTITE® 242®*
L	Motor mount bolts (rear)	41 N·m (30 lb ft)	Use LOCTITE® 242®*

* or equivalent


See Bolt Torque Table on page 5-2.



See Bolt Torque Table on page 5-2.



See Bolt Torque Table on page 5-2.



Power Pack

WARNING: You must leave your motorcycle on the charger if you expect it to sit in storage or unused for over 7 days.

The power pack must be charged within 24 hours if fully discharged, and charged within 60 days if stored fully charged.

Zero recommends you plug in your Zero motorcycle after 7 days, even if fully charged. Please leave your Zero motorcycle plugged in whenever possible.

1. The power pack is a lithium ion power system. While it does require charging, it does not require maintenance.
2. The power pack should be kept away from excessive heat. The lithium ion cells should not get above 71°C (160°F). Do not store in a hot car or trailer, or leave the power pack in direct sunlight.
3. Only an authorized service agent is qualified to have access to and troubleshoot the power pack.
4. Dispose of the power pack according to your state and local laws. It is encouraged that the power pack be recycled rather than disposed of in landfills. Please contact Zero at support@zeromotorcycles.com or locate a recycling center in your area.

General Maintenance

Motor

CAUTION: Wear safety glasses when using compressed air to avoid eye injury.

The motor requires little maintenance, but dust can collect inside the motor and can cause premature brush wear. If you ride in dusty conditions it is important to blow the dust out of the motor with compressed air. Do this only in a well-ventilated area.

Brakes


Brake Fluid Level Inspection

WARNING: Do not spill brake fluid on painted surfaces, the finish could be damaged. Spilling brake fluid on the ABS body plastics will cause them to crack. Clean off any brake fluid spills immediately.

Always place a shop towel under the master cylinder reservoir prior to removing cover/cap.

Low fluid levels may indicate worn brake pads or a leak in the hydraulic system. Inspect the brake pads for wear and/or the hydraulic system for leaks. Use only new DOT 4 brake fluid from a sealed container.


Front Brake



Inspect the level of the front brake fluid through the sight glass (B). If the fluid level is visibly below the low level indicator (C), brake fluid must be added. Clean any dirt or debris from the cover (A) before opening the reservoir.

1. Remove the two Phillips screws, securing the cover onto the reservoir.
2. Add new DOT 4 brake fluid.
3. Inspect the cover seal, ensuring that it is free of any wear or damage and that it is positioned correctly.
4. Install the cover and tighten the Phillips screws.

Rear Brake




Inspect the level of the rear brake fluid by inspecting the level through the reservoir housing. If the fluid level is visibly below the low minimum “MIN” indicator (B), brake fluid must be added. Clean any dirt or debris from the cap opening (A) before opening the reservoir. Unscrew the cap and add new DOT 4 brake fluid. Inspect the cap seal ensuring that it is free of any wear or damage then reinstall the cap.

Inspect the level of the rear brake fluid by inspecting the level through the reservoir housing. If the fluid level is visibly below the low minimum “MIN” indicator (B), brake fluid must be added. Clean any dirt or debris from the cap opening (A) before

Brake Pad Inspection

The brake pads must be inspected when specified in the maintenance schedule. See Maintenance Schedule on pages 5-23 through 5-25. Visually inspect the brakes by looking at the remaining brake pad material through the sides of the brake caliper. Replace the brake pads if either pad’s thickness is 1.35 mm (0.05 in) or less. If the brake pads (A) are worn, replace both brake pads immediately.



The brake rotor should also be checked for thickness. The minimum thickness is 3.85 mm (0.15 in).

Suspension

Front

For maintenance, see Maintenance Schedule on pages 5-23 through 5-25.

To adjust the fork, see Suspension Adjustment on page 4-17.

Rear

CAUTION: The shock absorber assembly contains highly pressurized gas.

- Do not attempt to tamper with or open the cylinder or shock.
- Do not subject the shock to high temperature or open flame.

Doing either of these can cause the cylinder or shock to explode causing personal injury or death.

For maintenance, see Maintenance Schedule on pages 5-23 through 5-25.

To adjust the shock, see Rear Shock Adjustment on page 4-19.

Wheels And Tires

Inspect both wheels for the following:

- Bent, loose, or missing spokes
- Bent or cracked rims
- Impact marks on the rims

Inspect both tires for the following:

- Cuts, cracks, splits, or missing tread lugs in the tread or sidewall area
- Bumps or bulges within the tire body
- Uneven tire tread wear. Wear on one side of the tire tread or flat spots in the tire tread indicate a problem with the tire or motorcycle.
- Exposed tire tread or cords

If either of the wheels or tires are found to have any of the above conditions, replace the wheel and tire immediately.

Tire Inflation

CAUTION: Under-inflation is the most common cause of tire failure and may result in severe tire cracking, tread separation, “blowout,” or unexpected loss of motorcycle control causing personal injury and possible death.

Tire pressure should be checked and adjusted before each ride. Tire pressure is checked using an accurate gauge when the tires are cold. This means that the tires have not been ridden on for 3 hours. Always replace the valve stem cap when finished.

MODEL	FRONT	REAR
S	220 kpa (32 psi)	241 kpa (35 psi)
DS	220 kpa (32 psi)	241 kpa (35 psi)

Drive Belt

The belt drive provides low maintenance and quiet operation with minimal stretch. Keep dirt, grease, oil, and debris off the belt and sprockets.

The drive belt tension should be checked and adjusted at the intervals specified in the Maintenance Schedule.

Clean the belt with mild soap and water when washing your motorcycle. Towel dry and inspect for the following:

- Cuts or unusual wear patterns.
- Damage to the center of the belt.
- Outside edge beveling. Some beveling is common but it indicates that sprockets are misaligned.
- Outside ribbed surface for signs of stone puncture.
- Inside (tooth portion) of belt for exposed tensile cords normally covered by nylon layer and polyethylene layer. This condition will result in belt failure and indicates worn sprocket teeth.
- Signs of puncture or cracking at the base of the belt teeth.

If any of the above conditions are found, the belt should be replaced.

Checking Drive Belt Tension


Proper belt tension is essential for optimum operation of the drive system.

Lack of belt tension can lead to so-called “ratcheting”. The teeth of the belt will slide over the teeth of the rear sprocket. This causes not only an unpleasant sound; the ratcheting can also cause damage to the carbon tensile cords. If ratcheting has occurred you should replace the belt before the next time you ride.

Too much tension can increase the wear of your drive system and the system can drag.

The tension is checked by using a tension tester.


The Tension Tester has a plastic measurement arm, located in a slot. Along this slot there is a measuring scale. The point of intersection of the measurement arm and the measuring scale shows the tension of the belt. There is a button (clicking pad) on the upper side of the Tension Tester, where you can secure your finger with a rubber band holder. A spring is located underneath this clicking pad. If a certain pressure is applied to the spring, it makes a clicking sound.



1. Remove the key from the key switch.
2. Press the Tension Tester steadily to the middle of the upper side of the belt. The “lip” will lead the tester to the belt.
3. Slowly increase the pressure on the tester, until you hear a clicking sound. Do not increase the pressure after the tester has clicked.
4. Remove the tester carefully from the belt. Avoid rough movements of the tester, as this would change the results of the measurement. The measurement should be in the range of 20-30 kg.

Drive Belt Adjustment Procedure


1. Remove the key from the key switch.
2. Loosen both rear motor mount 7/32" hex bolts (A).



3. Loosen both front motor mount 5/16" hex bolts (B). Loosen the 1/2" jam nut (C) on the belt tensioner.

Note: Belt tension will increase slightly when motor mounts bolts are fully torqued.

4. Turn the adjuster bolt (D) a 1/4 turn at a time until the belt free play is within specification.



5. Tighten all motor mount Allen bolts. See Bolt Torque Table on page 5-2.
6. Tighten the 1/2" jam nut on the belt tensioner.
7. Test ride the motorcycle.
8. Recheck the belt for proper adjustment after the test ride and readjust if necessary.

Drive Chain (Optional)

Cleaning The Drive Chain

CAUTION:

- Wear safety glasses when cleaning the chain to prevent eye injuries.
- Never have the motor spinning the wheel. Turn the wheel only by hand. Failure to do so could result in serious personal injury.
- Never place your hand or any other body part between the chain and sprockets. Work with the chain only in the middle between the two sprockets. Failure to do so could result in serious personal injury.
- Do not allow any of the cleaner to get on the brake rotors or brake pads. If the rotors are contaminated with cleaner, it will impair the motorcycle's ability to stop. This could result in serious personal injury.

Follow the manufacturer's instructions for the chain cleaner you are using; below are the general guidelines.

1. Remove the key from the key switch.

2. Set the motorcycle on a stand or lift so the rear wheel is free to spin. While turning the wheel by HAND, spray the inside of your entire chain with a good coating of chain cleaner and let it sit for a few minutes.
3. Using a brush, fill the bristles with spray from the chain cleaner. Begin gently scrubbing the chain on the top of your swingarm using the brush.
4. Do this for the entire length of the chain. Now do the same thing for the inside/bottom of the chain.
5. Using the brush, clean both sides of the rear sprocket. Let this soak for 5 minutes.
6. Using a water hose, rinse the entire chain. Then, using a clean rag, wipe any residual moisture from the chain.

Lubricating The Drive Chain

CAUTION:

- Wear safety glasses when lubricating the chain to prevent eye injuries.
- Never have the motor spinning the wheel. Turn the wheel only by hand. Failure to do so could result in serious personal injury.


- Never place your hand between the chain and sprockets. Work with the chain only in the middle between the two sprockets. Failure to do so could result in serious personal injury.
- Do not allow any of the lubricant to get on the brake rotors or brake pads. If the rotors are contaminated with lubricant, it will impair the motorcycle's ability to stop. This could result in serious personal injury.

Follow the manufacturer's instructions for the chain lubricant you are using; below are the general guidelines. Do not allow any of the lubricant to get on the brake rotor.

1. Turn the wheel backwards slowly and spray the inside of the chain on the inside of the links.
2. Turn the wheel backwards slowly and spray the outside of the chain on the outside of the links.
3. Let the motorcycle stand for 30 minutes to allow the lubricant to penetrate the link rollers.


Checking The Drive Chain

1. Remove the key from the key switch.
2. Using a ruler, grasp the chain halfway between the front and rear sprockets.
3. The chain should move 16 mm (.63 in) in either direction, so 32 mm (1.25 in) of total free play.
4. If the chain's free play is not within specifications it will need to be adjusted. See the Drive Chain Adjustment Procedure on page 5-15.



Drive Chain Adjustment Procedure


1. Remove the key from the key switch.
2. Loosen both rear motor mount 7/32" hex bolts (A).



3. Loosen both front motor mount 5/16" hex bolts (B).
4. Loosen the 1/2" jam nut (C) on the chain tensioner.

Note: Chain tension will increase slightly when motor mounts bolts are fully torqued.

5. Turn the adjuster bolt (D) a 1/4 turn at a time until the chain free play is within specification.
6. Tighten all motor mount hex bolts. See Bolt Torque Table on page 5-2.
7. Tighten the 1/2" jam nut on the chain tensioner.
8. Test ride the motorcycle.
9. Recheck the chain for proper adjustment after the test ride and readjust if necessary.




Headlight Alignment

The headlight should be checked for correct alignment periodically. It must be aligned any time the suspension sag is adjusted because this will affect the headlight alignment. Before the headlight can be aligned, the suspension sag and tire pressure must be correctly adjusted. The headlight can be adjusted horizontally and vertically. If the horizontal adjustment is off, the beam will point too far off to one side. If the vertical adjustment is off, it will cause the beam to point too close to or too far ahead of the motorcycle. With the headlight on the low beam position, the motorcycle perpendicular to the ground, and the operator sitting on the motorcycle, verify the beam alignment. The motorcycle is shipped with the headlight at a 0.5-2.5% dip.

To adjust the headlight horizontally, turn screw (B) until the correct beam alignment is achieved.

To adjust the headlight vertically, loosen the housing screws (A). Move the housing up or down until the correct beam alignment is achieved. Tighten the screws. See Bolt Torque Table on page 5-2.




Headlight Bulb Replacement


CAUTION: Halogen bulbs contain gas under pressure. Handling a bulb improperly could cause it to shatter into flying glass fragments. To help avoid personal injury:

- Turn off the key switch and allow the bulb to cool before changing the bulb.
- Leave the key switch OFF until the bulb change is complete.
- Always wear eye protection when changing a halogen bulb.
- Avoid touching the glass.


1. Remove the two screws (A) from the headlight housing.



2. Disconnect the main headlight connector (B). See image on page 5-18.



3. Working with the headlight on a bench, disconnect the headlight bulb connector and cover.
4. Unhook the headlight bulb spring clip (C) by (1) pushing down then (2) pushing to the side.
5. Lift up on the spring clip and remove the headlight bulb.




WARNING: Do not touch the glass portion of the headlight bulb. Keep the headlight bulb free of contaminants. Oil from your fingers or contaminants will shorten the life of the bulb. Thoroughly clean any fingerprints or contaminants from the bulb using a clean cloth moistened with alcohol.

6. Install the headlight bulb into the lens.
7. Install the headlight spring clip.
8. Install the headlight bulb cover; ensure that the arrow is pointing up.
9. Connect both connectors and install the headlight screws.


Turn Signal Light Bulb Replacement

1. Remove the turn signal lens screw (A) and remove the lens.
2. Push in on the bulb, turn the bulb counter-clockwise, and then pull the bulb out.
3. Insert the new bulb into the socket, push in and turn clockwise until it stops.
4. Install the lens and screw; tighten the screw. Do not over-tighten the screw otherwise the lens may break.



Brake/Tail Light Bulb Replacement


1. Remove the brake/tail light lens screws (A) and remove the lens. See image on page 5-20.



2. Push in on the bulb and turn the bulb counter-clockwise then pull the bulb out.
3. Insert the new bulb into the socket, push in and turn clockwise until it stops.
4. Install the brake/tail light lens and screws; tighten the screws. Do not over-tighten the screws otherwise the lens may break.


Running Light Bulb Replacement

1. Remove the two screws (A) from the headlight housing.



2. Remove the bulb socket (A) from the headlight using a rocking motion (see image on page 5-21).

3. Pull the old bulb out of the socket.
4. Push the new bulb into the socket and push the socket (A) into the headlight.
5. Install the headlight housing and screws.



Cleaning

To prolong the life of your motorcycle it should be washed periodically. Regular cleaning, using correct methods, is an important factor in maintaining the value of your motorcycle. It also ensures that safety-relevant parts remain in full working order.

CAUTION: After cleaning and before starting your journey, always test the brakes.

If tar, bugs, or other similar deposits have accumulated, wash them off as soon as possible. Do not use high pressure or steam cleaners; they can cause water intrusion of bearing, seals, and electrical components. Avoid spraying water of great force around the instrument panel, power pack, or controller. Avoid using strong acidic wheel cleaners, especially on spoked wheels. If such products are used on hard-to-remove dirt, do not leave the cleaner on the affected area any longer than instructed. Also thoroughly rinse the area off with water, immediately dry it, and then apply a corrosion protection spray.

WARNING: Improper cleaning can damage electrical components, cowlings, panels, and other plastic parts. Use only a soft, clean cloth or sponge with mild detergent and water to clean plastic.

Do not use any harsh chemical products on plastic parts. Be sure to avoid using cloths or sponges which have been in contact with strong abrasive cleaning products, solvent or thinner, fuel (gasoline), rust removers or inhibitors, brake fluid, antifreeze or electrolyte.

After gently washing the motorcycle, be sure to allow all of the electrical components to dry prior to operation. If the motorcycle is ridden immediately after being washed, apply both brakes several times in order to remove any moisture from the brake linings. Do not use products such as tire dressings on tires as this will deteriorate traction.

Parking And Long Term Storage

1. It is recommended to always leave the power pack plugged in. The Zero S/DS charger is designed to maintain a balanced and complete charge at all times without wasting any electricity.

2. Over extended periods of time the power pack is checked every 72 hours to ensure that the cells are balanced and that the power pack is full. Once the power pack has reached complete charge it is checked every 72 hours, remove over extended periods of time.
3. To prolong the life of your power pack you should store your motorcycle in a cool area. Storing your motorcycle in a hot area will cause your power pack's life to be shortened.
4. If, for some reason, your motorcycle was not plugged in for several days, you should always charge it up before riding.

For more information on the power pack and the electrical system see Battery Management System (BMS) on page 4-8.

WARNING: Opening of the power pack is for trained Zero Motorcycles' technicians. Please be aware that incorrect handling of a Zero power pack can be dangerous. **DO NOT OPEN!**

Maintenance Schedule

The scheduled maintenance must be performed in accordance with this chart to keep the Zero S/DS motorcycle in top running condition. The initial maintenance is vitally important and must not be neglected. Where time and mileage are listed, follow the interval that occurs first.

NO.	ITEM	ROUTINE	EVERY RIDE	INITIAL	ODOMETER MILEAGE READINGS					
				1,000 km (600 mi) or 1 month	7,000 km (4,000 mi) or 6 months	13,000 km (8,000 mi) or 12 months	19,000 km (12,000 mi) or 18 months	25,000 km (16,000 mi) or 24 months	31,000 km (20,000 mi) or 30 months	
1	Front Brake	• Check operation, and for fluid leakage. Replace brake pads if necessary.	✓	✓	✓	✓	✓	✓	✓	
2	Rear Brake	• Check operation, and for fluid leakage. Replace brake pads if necessary.	✓	✓	✓	✓	✓	✓	✓	
3	Brake Hoses	• Check for cracks or damage. Replace if necessary.	✓		✓	✓	✓	✓	✓	
4	Wheels	• Check runout, and for damage. Replace if necessary.			✓	✓	✓	✓	✓	
5	Tires	• Check tread depth, and for damage. Replace if necessary. • Check air pressure. See page 5-9. Correct if necessary.	✓		✓	✓	✓	✓	✓	

NO.	ITEM	ROUTINE	EVERY RIDE	INITIAL	ODOMETER MILEAGE READINGS					
				1,000 km (600 mi) or 1 month	7,000 km (4,000 mi) or 6 months	13,000 km (8,000 mi) or 12 months	19,000 km (12,000 mi) or 18 months	25,000 km (16,000 mi) or 24 months	31,000 km (20,000 mi) or 30 months	
6	Wheel Bearings	• Check bearings for smooth operation. Replace if necessary.			✓	✓	✓	✓	✓	
7	Motor Brush Assembly	• Blow out with a high pressure air hose.				✓				
8	Drive Chain	• Check chain slack/alignment and condition. • Adjust and lubricate chain with chain lubricant thoroughly. • Replace worn chain.	✓	Every 1,000 km (600 mi) and after washing the motorcycle or riding in the rain						
9	Drive Belt	• Check belt slack and condition. • Replace a worn/damaged belt. • Replace the belt every 20,000 km (12,500 mi)	✓							
10	Steering Bearings	• Check bearing assembly for looseness. • Moderately repack with Teflon® grease every 25,000 km (16,000 mi) or 24 months.		✓	✓	✓	✓	Repack	✓	
11	Chassis Fasteners	• Check all chassis fittings and fasteners. Correct if necessary.			✓	✓	✓	✓	✓	

NO.	ITEM	ROUTINE	EVERY RIDE	INITIAL	ODOMETER MILEAGE READINGS					
				1,000 km (600 mi) or 1 month	7,000 km (4,000 mi) or 6 months	13,000 km (8,000 mi) or 12 months	19,000 km (12,000 mi) or 18 months	25,000 km (16,000 mi) or 24 months	31,000 km (20,000 mi) or 30 months	
12	Front Brake Lever Pivot Shaft	• Apply silicon grease lightly.			✓	✓	✓	✓	✓	
13	Front Fork	• Check operation and for oil leakage. • Service/rebuild if necessary.	✓		✓	✓	✓	✓	✓	
14	Rear Shock Absorber Assembly	• Check operation and for oil leakage. Replace if necessary.	✓		✓	✓	✓	✓	✓	
15	Throttle Grip	• Check operation and free play.	✓		✓	✓	✓	✓	✓	
16	Kickstand Pivots	• Check operation. • Apply silicon grease lightly.			✓	✓	✓	✓	✓	
17	Kickstand Switch	• Check operation and replace if necessary.		✓	✓	✓	✓	✓	✓	

NOTE: From 37,000 km (24,000 mi) or 36 months, repeat the maintenance intervals starting from 13,000 km (8,000 mi) or 12 months.

Parts/Maintenance Items

The proper replacement parts, fluids, and lubricants to use are listed in the chart below.

PART	NUMBER
Headlight Bulb-55 watt	H4
Turn Signal Light Bulb	1156
Brake/Tail Lights Bulb	1157
Front Running Light Bulb	194
Brake Fluid	DOT 4

Zero Motorcycle Accessories

Zero accessories are designed to complement and function with other systems on your motorcycle. Your CSC can accessorize the motorcycle using genuine Zero accessories.

A full line of Parts, Accessories, and Apparel can be found on the Zero Motorcycles website.


Fuses

Whenever there is an excessive amount of current flowing through a circuit the fusible element will melt and create an open or incomplete circuit. Fuses are a one-time protection device and must be replaced each time the circuit is overloaded. Replace the fuse with one of equal current and voltage rating. Do NOT interchange 12 volt and 58 volt fuses. If the fuse melts repeatedly, have the electrical system inspected by your CSC.

Fuse Center Locations

12 Volt:

The 12 volt fuse center is located behind the front fork under the top trim panel.



The fuse center has a protective cover that must first be removed to gain access to the fuses. To remove the cover, squeeze the tabs (A) together and lift off the cover.


To access the 12 volt fuse center:

- Turn the forks to full lock.
- Remove the cover from inside the cavity.
- Replace the fuse.
- Reinstall the cover.

FUSE #	AMP	CIRCUITS CONTROLLED
1	10	Headlight, Flash-to-Pass
2	5	Fan
3	10	Turn Signals, Horn
4	5	Instrument Panel, Brake/Tail Light

58 Volt:


The 58 volt fuse center (A) is located on the back upper left corner of the power pack.



To access the 58 volt fuse center:

- Remove the cover to access the fuse.
- Replace the fuse.
- Reinstall the cover.

FUSE #	AMP	CIRCUITS CONTROLLED
1	10	Main Bike Board/Controller
2	10	DC/DC Converter
3	25	Charger
4	25	Quick Charger



Follow the maintenance schedules on pages 5-23 through 5-25. After a scheduled service or routine is performed, record the information on the chart below.


DATE	ITEM	SERVICE/ROUTINE DESCRIPTION

This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

All of the motorcycles are carefully inspected before they are delivered. Even after the motorcycles are inspected, some technical issues can occur. The following information offers a guide to help you to identify an issue, and if possible, repair it yourself. If you are unable to solve an issue with your Zero S/DS electric motorcycle, take it to an authorized Certified Service Center (CSC) at your convenience. If there is no CSC in your area call Zero Motorcycles Customer Service.

Power Pack And Charger







If a fault occurs during charging, count the number of times the red light (A) flashes on the charger in between pauses. See the table on page 6-2 for the possible cause and solution to the issue.



NUMBER OF RED FLASHES		CAUSE	SOLUTION
1	✱	Power Pack High Voltage	Reset charger (interrupt AC power for 15 seconds).
2	✱✱	Power Pack Low Voltage	Reset charger (interrupt AC power for 15 seconds).
3	✱✱✱	Charge Timeout caused by power pack not reaching required voltage. Charger output was reduced due to high temperatures.	Check connections. Operate charger at a lower ambient temperature.
4	✱✱✱✱	Power pack could not be trickle charged up to minimum voltage.	Contact CSC.
5	✱✱✱✱✱	Over-Temperature: Charger shut down due to high internal temperature.	Ensure sufficient cooling air flow and reset charger (interrupt AC power for 15 seconds).
6	✱✱✱✱✱✱	Charger Internal Fault	Reset charger (interrupt AC power for 15 seconds). Contact CSC if fault persists.

Understanding Beep Sequences

The Battery Management System (BMS) is located inside the power pack and is fitted with a beeper to provide audible notifications about the status of the power pack. Below you will find information on the meaning of the beep sequences.

PATTERN		WHEN	MEANING	SOLUTION
1 Short		Key-on	Self-Test Pass	BMS OK. Ready to ride!
1 Trill 2 Long		Key-on	Charger Still Plugged In	Unplug charger & try again.
2 Long		Key-on	Power Pack Empty	Charge power pack before riding.
4 Long		Key-on	Too Hot	Let power pack cool down.
5 Long		Key-on	Power Pack Unbalanced	Leave on charger for 72 hours.
4 Short 1 Long		Riding	Low-Power Pack Warning	Charge soon.

Power Pack Empty

If the power pack is completely empty, an error-beep will sound and the BMS will disable the throttle. You cannot ride the motorcycle until you recharge the power pack. If the Power Pack Empty error-beep still sounds after two hours of charging time, contact your CSC. Your power pack may need to be repaired or replaced.

Too Hot

The power pack contains internal temperature sensors. If the BMS measures excessive internal temperatures, it will sound an error-beep and disable the throttle. You cannot ride the motorcycle until the power pack cools down. Place the motorcycle in a cool, well-ventilated location and wait a few minutes before riding again. If the Too Hot error-beep still sounds after the power pack has had time to cool down, contact your CSC. Your power pack may need to be repaired or replaced.

Power Pack Unbalanced

The power pack contains many individual cells. The BMS continuously monitors the cells and tries to keep them all “in balance” (at the same level-of-charge). If any of the cells are grossly out-of-balance, the BMS will sound a Power Pack Unbalanced error-beep and disable the throttle. You cannot ride the motorcycle until the problem is resolved.

The solution to the problem is to plug in the charger and allow the power pack to charge for 72 hours. This will allow the BMS to re-balance the cells in the power pack. If the Power Pack Unbalanced error-beep still sounds after the power pack has spent more than 72 hours charging, contact your CSC. Your power pack may need to be repaired or replaced.

Low Power Pack Warning

The BMS provides a Low Power Pack warning telling the operator that the remaining range is limited, and the power pack should be recharged soon. This is equivalent to a “low fuel” warning-light on a gasoline-powered vehicle. This beep-warning is different from the others because it can sound at any time when the motorcycle is ON (the other warnings only sound when the key switch is first turned ON).

The Low Power Pack warning beep will sound continuously until either (1) the motorcycle is turned OFF, or (2) the throttle control is disabled for any reason, which includes the power pack being completely empty. The Low Power Pack warning beep will sound when you can still ride the motorcycle, but the remaining range is limited. It means: “Stop at a destination and charge-up.”

The solution is to recharge the power pack. If the Low Power Pack warning beep still sounds after the power pack has charged for two hours, contact a CSC. Your power pack may need to be repaired or replaced.

Other Error-Beep Patterns

If the BMS in your power pack produces an error-beep which is not described in the Beep Patterns Table, then the power pack has encountered a serious internal hardware problem and must be repaired or replaced by a CSC.

BMS Appendix



There are other beeps which may occur under two circumstances that operators will normally never see. Unlike many electronic systems, the BMS essentially never “power cycles.” A typical BMS is powered-on only once, in the factory, when it is connected to the wiring-harness inside the power pack. It may quite possibly operate continuously for years without ever being powered-down.

But on that one occasion when it is first powered-on, the BMS will perform a simple power ON self-test and report the result with a beep pattern. Note that this power ON self-test (and the resulting beep patterns) is different from the key on self-test. The self-test (and the beeps) happens immediately when the board is first powered up (connected to a power pack).

During service or maintenance, the BMS board may be disconnected from and then reconnected to the power pack wiring harness. In those cases, the BMS will perform the power ON self test (and result-beeps) every time it is plugged-in.

It is possible to encounter the power ON self-test result error-beeps from a badly malfunctioning or damaged power pack. If so, the user should return the power pack to Zero for repair or replacement.

Beep Patterns

PATTERN		WHEN	MEANING
2 Short		Pwr-on M-cmd	Pass Power ON self-test/ Mfg.test
3 Long		Pwr-on M-cmd	Fail Power ON self-test/ Mfg.test

Safety Interlocks

If the BMS detects a serious internal fault, it can take either or both of two actions to prevent damage to the power pack:

- Throttle Disable** The BMS will disable the throttle if the power pack is empty, or if the BMS detects certain serious internal problems. You cannot ride the motorcycle until the problem is resolved.
- Charger Disable** The BMS will prevent charging if it detects certain serious internal problems - even if the power pack is connected to a charger and plugged in to AC power. The power pack cannot be charged until the problem is resolved.

Throttle Disable Interlock

The BMS communicates with the main motorcycle control module. The BMS can send a signal to the main motorcycle controller requesting that the throttle control on the motorcycle be disabled. When the throttle control is disabled, the motor will not deliver power to the rear wheel, and the motorcycle cannot be ridden.

If the throttle is disabled while riding, the motorcycle will cease to provide power, and the operator must pull over to a safe location.

All conditions which would cause the BMS to disable the throttle are also signaled by an error beep pattern at self-test. If you suspect that the BMS has disabled the throttle control on your motorcycle, turn the key switch OFF and back ON again to enter self-test mode. The beep pattern from the BMS will report any of the error conditions which would cause the BMS to disable the throttle.

Each of these conditions, the associated self-test beep pattern, and the suggested remedies are discussed in Understanding Beep Sequences on page 6-3.

- Charger Still Plugged In
- Power Pack Empty
- Too Hot
- Power Pack Unbalanced

Charger-Disable Interlock

When the charger is attached and plugged in to AC power, the BMS communicates with the charger. The BMS can send a signal to the charger requesting that charging terminates immediately. When the charger is disabled, the indicator lights on the charger will show that charging has stopped.

There are two conditions that will cause the BMS to disable charging. One of these conditions is also reported by a self-test result beep pattern, the other is not.


Too Hot

If the BMS detects high internal power pack temperatures, it will both disable the throttle and prevent charging. This condition is also reported by an error beep pattern after BMS self-test when the motorcycle is turned ON. See Understanding Beep Sequences on page 6-3 for a description of the Too Hot error beep and the solutions.

Motor Temperature Indicator

PATTERN	MEANING
Slow Constant Blink	Motor Temperature Warning Stage 1
Fast Constant Blink	Motor Temperature Warning Stage 2
Intermittent Fast Blink	Motor Temperature Warning Stage 3
Indicator Always ON	Motor Temperature Disabled
2 Fast-Pause-2 Fast	High Power Pack Temperature

The Zero S/DS is equipped with a motor temperature sensor. In the unlikely event that you exceed the motorcycle's performance capabilities, it will provide you with an instrument panel illumination warning indicator (A).



Stage 1

The motor begins to reach an undesirable temperature:

- A slow blink is clearly seen on the warning indicator.

- You can continue to ride without performance interruptions.
- You should reduce speed - this will lower power output and the motor temperature to eliminate the blinking warning indicator.

Stage 2

If the motor continues to heat up:

- A fast blink is clearly seen on the warning indicator.
- The power to the motor begins to drop off, resulting in a noticeable reduction in available torque. This provides tactile feedback to the rider and also helps prevent the motor from heating further. As the motor cools again, full-power will be restored.
- At this point it is strongly recommended that you reduce your speed and consider finding a safe area to exit the road.
- You may still have time to back off the throttle to reduce heat. This will restore full power to the motor and eliminate the warning indicator.

Stage 3

If the critical temperature threshold of the motor is reached:

You will not reach this stage without knowingly ignoring stage 1 and stage 2.

- A ten second sequence of close intervals of rapid pulsing will be visible on the warning indicator and then power to the motor will be disabled.
- You must quickly find a safe place to park the motorcycle off of the road.
- When power to the motor is disabled the warning indicator goes solid.
- The motor should take no longer than about 10 minutes to cool.
- When the warning indicator turns off you can safely operate the motorcycle again.
- Use the throttle sparingly at first to ensure that the motor does not overheat.

Motor Temperature Disabled

This warning indicator is on solid. This is an indication that the motor temperature sensor is not detected. Check the connections to the temperature sensor. The connection is located in the motor cooling shroud near the top. If a problem is not found contact your CSC.

High Power Pack Temperature

If you see two fast blinks followed by two fast blinks this indicates that you need to let the power pack cool off in a well-ventilated location. If the high power pack temperature still exists after the power pack has had time to cool off, contact your CSC.

If the temperature warning indicator is blinking rapidly, please pull over and allow the power pack to cool off.

Power Pack Full (High Power Pack-Voltage)

If the BMS detects that the power pack is already full, it will disable further charging to prevent damage to the power pack.


This is not an error-condition; it is the result of a successful charging-cycle. There is no self-test error-beep which reports this condition.











During an ordinary charging cycle, when the cells are balanced, the charger (not the BMS) will sense that the power pack is full and terminate the charging-cycle with a "green light." The BMS does have a redundant back-up mechanism to prevent overcharging of the power pack. If the charger fails to terminate a charging-cycle when the power pack is full, the BMS will terminate charging itself to prevent damage.

Instrument Panel

System Warning Indicator

If a fault has been detected, count the number of times the red LED (A) flashes. Refer to the tables on pages 6-12 and 6-13 for possible cause and solution to the issue.



NUMBER OF RED FLASHES		CAUSE	SOLUTION
1		Motorcycle disabled due to motor stop switch or kickstand switch	Motor stop switch is in the OFF position. Press the motor stop switch ON button or kickstand is down. Raise kickstand.
2		Self-Test Failed	Contact Zero or CSC.
3		Charger Connected	Unplug charger.
4		High Throttle Disable	Throttle is ON or throttle/connection is bad Verify throttle action and/or check connection.
5		Pre-Charge Failed	Could not pre-charge motor controller. Contact CSC.
6		Low Power Pack Disable	Charge Power Pack Before Riding.
7		Contactor Error	Contact Zero or CSC.
8		Controller Area Network (CAN) Error	Contact Zero or CSC.
9		Battery Management System (BMS) Throttle Disable	Contact Zero or CSC.
10		Throttle Out of Range	Bad throttle or connections. Verify throttle action and/or check connection.

NUMBER OF RED FLASHES		CAUSE	SOLUTION
11	■ ■ ■ ■	Motor Temperature Sensor Out of Range	Bad motor temperature sensor or connections. Replace temperature sensor and/or check connections.
12	■ ■ ■ ■ ■ ■	MBB Voltage Error	Contact Zero or CSC.
13	■ ■ ■ ■ ■ ■ ■ ■	Board Temperature Warning	Board may have overheated. Let the motorcycle cool down.
14	■ ■ ■ ■ ■ ■ ■ ■ ■ ■	Current Sensor Error	Problem with current sensor or connection. Contact CSC.
15	■ ■ ■ ■ ■ ■	Board Temperature Sensor Out of Range	Problem sensing temperature of board. Contact CSC.
16	■ ■ ■ ■ ■ ■ ■ ■	High Current Disable	Turn the ignition OFF and ON. If problem persist contact Zero or CSC.
17	■ ■ ■ ■ ■ ■ ■ ■ ■ ■	Temperature Protection Error	Turn the ignition OFF and allow to cool off and then restart. If problem persist contact Zero or CSC.
18	■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■	Throttle Output Error	Turn the ignition OFF and ON. If problem persist contact Zero or CSC.
19	■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■	Miscellaneous Error	Contact Zero or CSC.

General Troubleshooting

SYMPTOM	POTENTIAL CAUSE	POTENTIAL SOLUTION
Motorcycle does not turn on	Power Pack not charged Key not properly engaged Main service power cut-off disconnected. Motor stop switch turned OFF	Charge Power Pack. Recheck key in ignition, turn OFF/ON again. Connect the main service power cut-off connection. Press the motor stop Switch ON button.
Charger not working	A/C power missing Main service power cut-off disconnected.	Check A/C outlet for power, A/C source check fuse/voltage. Connect the main service cut-off connection.
Handlebars wobbly (shimmy)	Incorrect tire pressure	Inflate to correct tire pressure. See page 5-9.
	Deformed front tire	Replace/balance front tire with the same tire supplied from the factory.
	Bald tire (excess wear)	Replace/balance tire with the same tire supplied from the factory.
	Loose headset bearings	Inspect the headset for wear or damage replace any worn or damaged parts. Tighten the headset pre-load.

Customer Assistance

Zero Motorcycles Inc. can be contacted via the contact methods listed below. Please have the following available as they are essential to effectively and efficiently answer your questions or resolve your concerns.

- Owner's name and address
- Owner's telephone number
- Vehicle identification number (VIN)
- Date of purchase
- Power Pack serial number
- Motor serial number

An owner information chart is provided on page 1-3 to record this information.

Zero Motorcycles
170 Technology Circle
Scotts Valley, California 95066
USA

Phone:
(888) 786-9376
Monday-Friday
8am to 5pm Pacific Time

E-mail:
support@zeromotorcycles.com
24 hours

Warranty Information

LIMITED WARRANTY COVERAGE			
MOTORCYCLE PARTS COVERED	STANDARD		EXTENDED (Replaces 2nd Year of the Standard Warranty)
	First Year	Second Year (Excluding Shipping and Labor)	
Motor	✓	✓	✓
Controller	✓	✓	✓
Power Pack	✓	✓	✓
Fork	✓	✓	✓
Rear Shock	✓	✓	✓
Frame	✓	✓	✓
Swingarm	✓	✓	✓
Brake Assemblies	✓	✓	✓
Electrical	✓	✓	✓
Wheels	✓*	*	✓*

* No warranty on dirt bike wheels once ridden.

Zero Motorcycles Limited Warranties

Zero Motorcycles Inc. expressly warrants all Zero manufactured products from defects in material and workmanship to the original owner under normal operating conditions and according to proper use for 2 years from the date of delivery.

These warranties are transferrable subject to a \$50 processing fee and a new registration card to subsequent owners.

Standard Warranty

The first year of this standard limited warranty covers parts, standard shipping and labor for all major components, defined herein as including the motor, motor controller, power pack, frame, swingarm, fork, rear shock, brake assemblies, wheels, and electrical sub-assemblies.

This warranty covers Zero manufactured accessories installed at the time of purchase.

The second year of this standard limited warranty covers parts only for these same major components.

Standard Warranty Exclusions

This warranty does not apply to tire wear, chain or sprocket condition, brake pads or rotors, fork seals, grips, foot pegs, the seat, or any other parts subject to normal wear and tear. Wheels are excluded from this standard warranty on off-road bikes once they have been ridden.

This standard warranty excludes aftermarket accessory kits which may be subject to their own warranties.

This standard warranty excludes parts and components damaged by use or operation under abnormal circumstances or contrary to the requirements described in the owner's manual, or damaged by improper use or accidents.

Racing or competitive use voids this warranty.

Modifications or alterations to major components of the manufacturer's original product or its sub-components void all warranties. Zero Motorcycles Inc. assumes no liability for any misuse or improper operation of Zero motorcycles.

Under this limited warranty and liability agreement, Zero Motorcycles Inc. shall have no obligation and the purchaser shall have no remedy against Zero Motorcycles Inc. and its officers and/or agents for any damages, including but not limited to incidental, consequential, special, punitive damages arising from direct or indirect injury to person or property, or any other loss, whether or not occasioned by negligence or otherwise on the part of Zero Motorcycles Inc.

Extended Warranty

The extended warranty is available for purchase by the original owner within 90 days of the date of delivery of the covered product. This replaces second year of the Standard Two Year Warranty with the additional coverage of Shipping and Labor, matching the coverage you receive in the first year.

Extended Warranty Exclusions

This warranty does not apply to tire wear, chain or sprocket condition, brake pads or rotors, fork seals, grips, foot pegs, the seat, or any other parts subject to normal wear and tear. Wheels are excluded from this extended warranty on off-road bikes once they have been ridden.

This extended warranty excludes aftermarket accessory kits which may be subject to their own warranties.

This extended warranty excludes parts and components damaged by use or operation under abnormal circumstances or contrary to the requirements described in the owner's manual or damaged by improper use or accidents.

Racing or competitive use voids this warranty.

Modifications or alterations to major components of the manufacturer's original product or its sub-components void all warranties. Zero Motorcycles Inc. assumes no liability for any misuse or improper operation of Zero motorcycles.

Under this limited warranty and liability agreement, Zero Motorcycles Inc. shall have no obligation and the purchaser shall have no remedy against Zero Motorcycles Inc. and its officers and/or agents for any damages, including but not limited to incidental, consequential, special, punitive damages arising from direct or indirect injury to person or property, or any other loss, whether or not occasioned by negligence or otherwise on the part of Zero Motorcycles Inc.

Disclaimers Applicable to Standard Warranty and Extended Warranty

The purchaser acknowledges that there is an inherent risk in the operation of Zero motorcycles and all other Zero Motorcycles Inc. products, and herewith assumes liability for any injury arising from all operation of any Zero Motorcycles Inc. product. The original registered owner or subsequent registered transferee as documented on the Zero motorcycle warranty registration form will indemnify and hold Zero Motorcycles Inc. harmless and take full responsibility for conveying all safety warnings, instructions and limited warranty if the unit is sold, loaned or otherwise transferred to other persons, and will indemnify Zero Motorcycles Inc. from any claims against it for original owner's failure to do so.

Zero Motorcycles Inc. does not assume or authorize anyone to assume for them any other obligation. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Zero Motorcycles Inc. assumes no responsibility for incidental, consequential or other damages including but not limited to: expense of returning the Zero

product to a certified service center, expense of delivering it back to the owner, mechanic's travel, time, communication charges, rental of a like product during the time the warranty service is being performed, travel, loss or damage to personal property, loss of revenue, loss of use of the product, loss of time, or inconvenience. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Zero Motorcycles Inc. reserves the right to change or improve the design of any electric motorcycle product without assuming any obligation to modify any product previously manufactured.

These warranties give you specific legal rights, and you also have other rights, which vary from state to state and country to country. These warranties apply to all Zero products manufactured by Zero Motorcycles Inc.

Normal operating conditions ***require routine care and maintenance by the purchaser*** of the Zero Motorcycles Inc. electric motorcycle and power pack.

Proper Use

For the purposes of these warranties, ‘proper use’ means only the use of a motorcycle in the manner intended for a single rider with proper safety equipment as described in the Owner’s Manual on safe and dry surfaces in accordance with local regulations. “Proper use” also means charging the Power Pack after each use and storing it in a fully charged state, or recharging it every 7 days, or keeping it on the charger when in storage or out of regular use.

Purchaser’s Responsibilities

Read and understand the Owner’s Manual and all product warnings before operating your Zero Motorcycles Inc. electric motorcycle. Serious injury or death may result from improper operation or failure to observe warnings and safety instructions on any motorized motorcycle or vehicle.

Submit the warranty registration card for your Zero motorcycle within the required time period as printed on the registration card.

Perform routine care and maintenance of your Zero Motorcycles Inc. electric motorcycle and power pack as detailed in the Owner’s Manual.

The rider is responsible for learning and obeying all federal, state, and local laws governing the operations of an electric motorcycle.

Always wear a helmet, knee and elbow guards, goggles, appropriate boots and all other appropriate safety equipment when operating a motorcycle.

Warranty Procedures

Warranty services may be obtained by contacting Zero Motorcycles Inc. at (888) 786-9376 or via e-mail at support@zeromotorcycles.com.

Service may also be available from a local Zero Motorcycles Certified Service Center; please see the locator on www.zeromotorcycles.com for the nearest location.

In any written or telephonic communication, please state the specific nature of and any circumstances leading to the problem. A service technician will contact you with specific instructions to ensure that you receive the best service for your motorcycle.

Zero Motorcycles
170 Technology Circle
Scotts Valley, CA 95066
USA

(U.S. and International Patents and Trademarks
Pending)

Transfer Of Ownership And Warranty

When it comes time to sell your Zero motorcycle, please visit the Zero Motorcycles website and access the Owner Resources section to fill out the on-line transfer of ownership and warranty form. This must be performed to allow Zero Motorcycles the ability to contact the new owner in the unlikely event of a safety related issue. Use the URL address listed or feel free to contact the Zero Motorcycles Customer Service department for assistance.

Phone:
(888) 786-9376
Monday-Friday
8am to 5pm Pacific Time

E-mail:
support@zeromotorcycles.com
24 hours

For updates and additional information about your motorcycle, visit the Owner Resources section of Zero Motorcycles' website at:
<http://www.zeromotorcycles.com/owner-resources/>

U.S. Manufacture:

Zero Motorcycles
170 Technology Circle
Scotts Valley, CA 95066.

All illustrations and specifications contained in this Owner's Manual are based on the latest product information available at the time of printing. Zero reserves the right to make changes at any time, without notice, in colors, materials, equipment, specifications and models.

Zero may, subject to legal requirements, determine the Model Year designations of its vehicles. The Model Year designation on any particular model may be longer or shorter than 12 months.

Some vehicles pictured may contain non-U.S. equipment. Some models may be shown with optional equipment.

While Zero Motorcycles makes all reasonable efforts to provide accurate information in this Owner's Manual, there is no guarantee or warranty of accuracy. Furthermore, we do not assume any liability for the accuracy of completeness of information presented.

This Owner's Manual shall not be used or relied upon as a substitute for information that is available from your Zero Motorcycles dealer. Further information can be obtained from your authorized Zero dealer or Zeromotorcycles.com.

©2011 Zero Motorcycles Inc. Not to be reproduced wholly or in part without written permission of Zero Motorcycles Inc. The Zero Motorcycles name, model names and logo are registered trademarks.

A	
Accessories	5-26
Add On Electrical Equipment	4-7
An Important Message To You From Zero	1-1
B	
Battery Management System (BMS)	4-8
Beep-Signals	4-8
Dangerously Low Voltage	4-8
High or Low Temperature	4-8
High Voltage	4-8
Low Voltage	4-8
Safety Interlocks	4-9
Beep Patterns	6-6
Beep-Signals	4-8
Beeps	4-9
BMS Appendix	6-5
Bolt Torque Table	5-2
Brake Fluid Level Inspection	5-6
Brake Pad Inspection	5-7
Brakes	4-4, 5-6
Brake Fluid Level Inspection	5-6
Brake Pad Inspection	5-7
Front Brake	5-6
Rear Brake	5-7
Brake/Tail Light Bulb Replacement	5-19
Braking	4-16
C	
Chain	5-13
Checking The Drive Chain	5-14
Cleaning The Drive Chain	5-13
Drive Chain Adjustment Procedure	5-15
Lubricating The Drive Chain	5-13
Charger Disable Interlock	6-6, 6-7
Charger LED Indicators	4-10
Charging The Power Pack	4-12
Checking Drive Belt Tension	5-10

Checking The Drive Chain	5-14
Cleaning	5-21
Cleaning The Drive Chain	5-13
Controls And Components	3-1
Customer Assistance	7-1

D

Dangerously Low Voltage	4-8
Disclaimers Applicable to Standard	
Warranty and Extended Warranty	7-5
Drive Belt	5-9
Checking Drive Belt Tension	5-10
Drive Belt Adjustment Procedure	5-12
Drive Chain	4-4, 5-13
Checking The Drive Chain	5-14
Cleaning The Drive Chain	5-13
Lubricating the Drive Chain	5-13
Drive Chain Adjustment Procedure	5-15

E

Electrical System	4-4
Emissions Information	1-10
Extended Warranty	7-4

INDEX-2

F

First Time Set-Up	4-1
Fork Lock Positions	4-5
Front Brake	5-6
Front Fork Adjustment	4-17
Fuse Center Locations	5-27
Fuses	5-26
Fuse Center Locations	5-27

G

General Information	1-6
Zero DS Technical Specifications	1-7
Zero S Technical Specifications	1-6
General Maintenance	5-6
Brakes	5-6
Brake/Tail Light Bulb Replacement	5-19
Cleaning	5-21
Drive Belt	5-9
Drive Chain	5-13
Headlight Alignment	5-16
Headlight Bulb Replacement	5-17
Maintenance Schedule	5-23
Motor	5-6

Parking And Long Term Storage	5-22
Running Light Bulb Replacement	5-20
Suspension	5-8
Tire Inflation	5-9
Turn Signal Light Bulb Replacement	5-19
Wheels And Tires	5-8
General Operation	4-4
Key Switch/Fork Lock Positions	4-5
Pre-Ride Inspection	4-4
Main Service Power Cut-Off	4-6
Power Pack	4-7
General Safety Precautions	2-1
General Troubleshooting	6-14

H

Handlebar Controls	3-10
Headlight Alignment	5-16
Headlight Bulb Replacement	5-17

I

Important Operating Information	2-2
Indicators	3-8

Instrument Panel	3-7, 6-11
Introduction	1-1

K

Key Code Number	1-4
Key Switch Positions	4-5

L

Left Side View	3-3
Limited Warranties	7-3
Location Of Important Labels	2-3
Throttle And Speed Control Label	2-4
Low Power Pack Warning	6-4
Lubricating The Drive Chain	5-13

M

Main Service Power Cut-Off	4-6
Maintaining Your Motorcycle	5-1
Maintenance Schedule	5-23
Motor	5-6
Motorcycle Controls	3-1
Left Side View	3-3

Right Side View	3-5
Motor Serial Number	1-4
Motor Temperature Indicator	6-8
High Power Pack Temperature	6-10
Motor Temperature Disabled	6-10
Power Pack Full	6-10

O

Operating Information	2-2
Operating Your Motorcycle	4-16
Braking	4-16
Starting	4-16
Stopping	4-16
Optimizing Your Range By Adapting Your	
Riding Style	1-9
Owner Information	1-3
Owner's Responsibilities	5-1

P

Parking And Long Term Storage	5-22
Parts/Maintenance Items	5-26
Performance Envelope	2-4

Performance Specifications/Operation Guidelines	2-4
Plug in Your Z-Force Power Pack™	1-2
Power Pack	4-4, 4-7, 5-5
Power Pack And Charger	6-1
Power Pack Charger	4-9
Power Pack Empty	6-4
Power Pack Full (High Power Pack-Voltage)	6-10
Power Pack Serial Number	1-4
Pre-Ride Inspection	4-4
Brakes	4-4
Drive Belt	4-4
Drive Chain	4-4
Electrical System	4-4
Power Pack	4-4
Throttle	4-4
Tires	4-4
Proper Use	7-6
Public Charging Stations	1-10
Purchaser's Responsibilities	7-6

Q

Quick Charging	4-14
----------------------	------

R

Rear Brake	5-7
Rear Shock Adjustment	4-19
Right Side View	3-5
Running Light Bulb Replacement	5-20

S

Safety Information	2-1
Safety Interlocks	4-9, 6-6
Standard Charging	4-12
Standard Warranty	7-3
Starting	4-16
Starting And Operating	4-1
Stopping	4-16
Suspension	5-8
Front	5-8
Rear	5-8
Suspension Adjustment	4-17
Front Fork Adjustment	4-17
Rear Shock Adjustment	4-19
System Warning Indicator	6-11

T

Technical Specifications	1-6
Zero DS Technical Specifications	1-7
Zero S Technical Specifications	1-6
Tension Tester	5-10
Throttle And Speed Control Label	2-4
Throttle Disable Interlock	6-6
Tire Inflation	5-9
Tires	4-4
Torque Table	5-2
Transfer Of Ownership And Warranty	7-7
Transporting	1-11
Troubleshooting	6-1
Turn Signal Light Bulb Replacement	5-19

U

Unpacking Your Zero Motorcycle	4-2
Understanding Beep Sequences	6-3
Low Power Pack Warning	6-4
Other Error-Beep Patterns	6-5

Power Pack Empty	6-4
Power Pack Unbalanced	6-4
Too Hot	6-4
Useful Information for Safe Riding	1-2

V

Vehicle Identification Number (VIN)	1-4
VIN Break Down	1-5
VIN Location	1-4
Vehicle Range	1-9

W

Warranty	7-3
Disclaimers	7-5
Extended	7-4
Limited Warranty	7-3
Standard Warranty	7-3
Transfer Of Ownership And Warranty	7-7

Warranty/Customer Assistance	7-1
Warranty Information	7-2
Warranty Procedures	7-6
Wheels And Tires	5-8

Z

Z-Force Air Induction System	2-5
------------------------------------	-----